
















BAKE PREP - PASTRY TOOLS

Picture	Code	Description
	7042-1	BISCUIT/COOKIE GUN
	7077	CAKE TESTER
	7115	CREAM HORNMOULDS 6s
	7676	PASTRY BOARD SCRAPER S/S
	7013	PASTRY BLENDER (NEW)
	7681	PASTRY BRUSH FLAT 25mm

Picture	Code	Description
	7682	PASTRY/BRAAI BRUSH ANGLED 50mm
	7683	PASTRY BRUSH FLAT 50mm
	7692	PASTRY CRIMPER
	7701	PASTRY LATTICE CUTTER
	7783	ROLLING PIN MINI 15cm
	7785	ROLLING PIN 50cm
	7786	ROLLING PIN WITH HANDLE 46cm

Picture	Code	Description
	7826	SCOOP WOOD MINI 6cm
	7826-3	SCOOP WOOD MINI 6cm 3s
	7826-6	SCOOP WOOD MINI 6cm set of 6
	7828	SCOOP WOOD TYPEA 14.5cm
	7829	SCOOP WOOD TYPED 14cm
	7830	SCOOP WOOD TYPED 18cm
	7831	SCOOP WOOD TYPED 25cm

Picture	Code	Description
	7874	SPATULA SWEDISH SUPERFLEX
	7881	SPOON BEECH 25 &35cm
	7882	SPOON BEECH 25cm
	7883	SPOON BEECH 30cm
	7884	SPOON BEECH 35cm
	7884-2	SPOON BEECH 30 & 35cm
	7885	SPOON BEECH 40cm

Picture	Code	Description
	7885GS	SPOON SET WOOD 3pce 30, 35 & 40